

## Bellow

Bellow for QME Linear Unit.

Note that “stroke” for a L+R unit refers to the stroke of each individual slider.

Bellows are recommended for all applications where the unit isn't protected against dust and dirt. The bellow may also work as a squeeze protection.

Dimensions in mm.



## General Data

Designation	Bellow Ltot	Bellow R+L Ltot
QME12-B	stroke * 1.286 + 110	stroke * 2.572 + 195
QME20-B	stroke * 1.200 + 162	stroke * 2.4 + 292
QME30-B	stroke * 1.146 + 234	stroke * 2.292 + 434