## **ST Stainless Dustproof Tape**

Stainless steel ST dustproof tape improves rail face sealing and works in conjunction with guide block seals.

Conventional plastic plugs do not offer the same improved sealing performance.


## Installation of ST tape:

- 1. After assembling a rail to the bed, clean the surface of the rail and remove any oil.
- 2. Attach the ST tape slowly over the rail length to within 2 or 3 mm from each end of the rail.
- 3. After attachment to the rail, apply pressure with dry cloth 3 or 4 times along the length of the rail to release encapsulated epoxy. Tape should be applied 4 to 6 hours prior to use to allow initial bonding.

Note: It is strongly recommended to wear safety gloves, the edge of this tape is sharp and can cut as you attach it to the rail.



## **Dimensions**



| Designation | w  | t   |
|-------------|----|-----|
| SBI15ST     | 11 | 0,1 |
| SBI20ST     | 15 | 0.1 |
| SBI25ST     | 17 | 0.1 |
| SBI30ST     | 21 | 0.1 |
| SBI35ST     | 27 | 0.1 |
| SBI45ST     | 37 | 0.1 |
| SBI55ST     | 43 | 0.1 |
| SBI65ST     | 51 | 0.1 |